

ALABASTER

COLOR	MIXING	SPRAY BOTTLE SETTING	APPROXIMATE SURFACE COVERAGE	BEFORE NEXT STEP	TIME TO DO
WICKENBURG WHITE	4 oz. to 16 oz. water	Mist	50%	While still wet go to next step.	5 min.
BLINDING WHITE	4 oz. to 16 oz. water	Mist	50%	While still wet go to next step.	5 min.
BLINDING WHITE	4 oz. to 16 oz. water	Mist	100%	1. Allow to dry 5-10 minutes, 2. Then blot spotted areas to soften as desired.	15 min.
<i>YOUR CHOICE</i> <i>Wickenburg White</i> <i>or Cherokee or</i> <i>Stonehenge</i>	3 CAPS. to 24 oz. water	Mist	5-10%	Light blot to soften color as desired. Be sure to keep clean edge on your blotting cloth.	15 min.

SEAL THE NEXT DAY USING OUR URETHANE SEALER --- NOT CRYSTAL TOP!

