

For this finish you will need:

- 1. Stonehenge-Dispersion
- 2. Ponderosa Green Acryli-Shade
- 3. Desert Brown Acryli-Shade
- 4. Antique White Acryli-Shade
- 5. Black FX

Mixing Procedure:

- 1. Mix Stonehenge (2 caps to 24oz of water) into a *Granicrete* professional spray bottle.
- 2. Mix Ponderosa Green (4oz to 20oz of water) into a *Granicrete* professional *spray bottle*.
- 3. Mix Desert Brown (4oz to 20oz of water) into a *Granicrete* professional *spray bottle*

Antique White Granite



- 4. Mix Antique White (4oz to 20oz of water) into a *Granicrete* professional *spray bottle*
- 5. Mix Black FX (2 caps to 24oz of water) into a *Granicrete* professional *spray bottle*

Step-by-Step Procedure:

- **1**. Apply all Granicrete Countertop Blend coats per installation instructions.
- 2. Mist and speckle 90% of the surface using Stonehenge. While still wet, proceed.
- 3. Mist and speckle 35% of the surface using Ponderosa Green. While still wet, proceed.
- 4. Mist and speckle 40% of the surface using Desert Brown. While still wet, proceed.
- 5. Mist and speckle 70% of the surface using Antique White. While still wet, proceed.
- 6. Mist and speckle 50% of the surface using Black FX.
- 7. Allow surface to completely dry and then apply Granicrete Crystal Top Epoxy per product instructions.

Professional Tip: Constantly shake up FX colors while being used in a spray bottle. The powder within each FX color is what makes them unique. If the color rest in the spray bottle the powder will settle to the bottom.

Antique White Granite Notes: