

Badgercrete

COLOR	MIXING	SPRAY BOTTLE SETTING	APPROXIMATE SURFACE COVERAGE	BEFORE NEXT STEP	TIME TO DO
CHEROKEE	3 CAPS to 24 oz. water	Mist	100%	<ol style="list-style-type: none"> 1. Blot white spots only allowing for heavy and light colored areas. 2. Allow to dry 30-60 minutes before going to next step. 	15 min.
GROUTLINE GREY	3 CAPS to 24 oz. water	Mist	100%	<ol style="list-style-type: none"> 1. Allow to dry 10 minutes. 2. Then blot to soften the entire surface. 	25 min.
WICKENBURG WHITE	4 oz. to 16 oz. water	Mist	100%	While still wet go to next step	5 min.
GROUTLINE GREY	3 CAPS to 24 oz. water	Mist	20-30%	Lightly blot to desire softening of colors.	10 min.

