

# BUCKSKIN

COLOR	MIXING	SPRAY BOTTLE SETTING	APPROXIMATE SURFACE COVERAGE	BEFORE NEXT STEP	TIME TO DO
CHEROKEE	3 CAPS to 24 oz. water	Mist	70%	While still wet begin next step	15 min.
STONEHENGE	3 CAPS to 24 oz. water	Mist	30% targeting the white areas	<ol style="list-style-type: none"> <li>1. Lightly blot with rag to pull up puddles, to soften and even color out, then...</li> <li>2. <b>ALLOW TO DRY 1 HOUR BEFORE SNOW CAP</b></li> </ol>	15 min.
BLINDING WHITE	4 oz. to 16 oz. water	Mist	30-40%	While still wet begin next step	15 min.
STONEHENGE	3 CAPS to 24 oz. water	Mist	30-40%	While still wet begin next step	15 min.
CHEROKEE	3 CAPS to 24 oz. water	Mist	30-40%	Lightly blot as did before	15 min.

