

# BURL

COLOR	MIXING	SPRAY BOTTLE SETTING	APPROXIMATE SURFACE COVERAGE	BEFORE NEXT STEP	TIME TO DO
WALNUT ACRYLIC CONCRETE STAIN	4 oz. to 4 oz. water	Mist	100%	While still wet go to next step.	5 min.
CHARCOAL ACRYLIC CONCRETE STAIN	4 oz. to 4 oz. water	Mist	100% and fill light areas left from Walnut	While still wet go to next step.	5 min.
WALNUT ACRYLIC CONCRETE STAIN	4 oz. to 4 oz. water	Mist	100%	Allow to dry as is or blot to desired soften finish.	15 min.

**SEAL THE NEXT DAY!**

