



GRANICRETE
INTERNATIONAL

Black Lace



For this finish you will need:

1. Black FX
2. Blinding White – Acryli-Shade
3. Brick Red FX

Mixing Procedure:

1. Mix Black FX (2oz to 20oz of water) into a *Granicrete* professional spray bottle.
2. Mix Blinding White (4oz to 20oz of water) into a *Granicrete* professional spray bottle.
3. Mix Brick Red FX (2oz to 20oz of water) into a *Granicrete* professional spray bottle

Step-by-Step Procedure:

1. Apply all Granicrete Countertop Blend coats per installation instructions.
2. Stream and flood 100% of the surface using Black FX. While still wet, proceed.
3. Stream and streak 30% of the surface using Blinding White. While still wet, proceed.
4. Stream and spot flood 10% of the surface using Brick Red FX. Allow to dry before proceeding.
5. Stream and speckle 60% of the surface using Black FX.
6. Allow surface to completely dry and then apply Granicrete Crystal Top Epoxy per product instructions.

Professional Tip: Constantly shake up FX colors while being used in a spray bottle. The powder within each FX color is what makes them unique. If the color rest in the spray bottle the powder will settle to the bottom.

Black Ice Notes: