

CAPPUCCINO

EASYDIY COLOR	MIXING	SPRAY BOTTLE SETTING	APPROXIMATE SURFACE COVERAGE	BEFORE NEXT STEP	TIME TO DO
CAPPUCCINO	4 oz. to 4 oz. water	Mist	100%	While still wet go to next step.	5 min.
WALNUT	4 oz. to 4 oz. water	Mist	100%	While still wet go to next step.	5 min.
CHARCOAL	4 oz. to 4 oz. water	Mist	100%	Blot spotted areas to soften as desired.	15 min.
CAPPUCCINO	4 oz. to 4 oz. water	Mist	100%	<ol style="list-style-type: none">1. Allow to dry 5-10 minutes,2. Then blot spotted areas to soften as desired.	15 min.

SEAL THE NEXT DAY... Please closely follow the video's directions.

