

# CINNAMON

COLOR	MIXING	SPRAY BOTTLE SETTING	APPROXIMATE SURFACE COVERAGE	BEFORE NEXT STEP	TIME TO DO
WALNUT ACRYLIC CONCRETE STAIN	12 oz. to 12 oz. water	Mist	90-100%	While still wet begin next step	5 min.
CAPPUCCINO ACRYLIC CONCRETE STAIN	12 oz. to 12 oz. water	Mist	50%	Lightly blot and then allow to dry 30 minutes <b>before</b> doing the next step	5 min.
WALNUT ACRYLIC CONCRETE STAIN	12 oz. to 12 oz. water	Mist	100%	<ol style="list-style-type: none"><li>1. Allow to set for 5-10 minutes.</li><li>2. Then blot drops still remaining to soften and blend colors as desired.</li></ol>	20 min.

**SEAL THE NEXT DAY!**

