

Cherry Web



For this finish you will need:

1. Black FX
2. Taupe-Dispersion
3. Black Webbing Spray
4. White Webbing Spray

Mixing Procedure:

1. Mix Black FX (2 caps to 26oz of water) into a *Granicrete* professional spray bottle.
2. Mix Taupe (2 caps to 26oz of water) into a *Granicrete* professional spray bottle.

Step-by-Step Procedure:

1. Apply all Granicrete Countertop Blend coats per installation instructions.
2. Mist and flood 100% of the surface using Black FX. While still wet, proceed.
3. Mist and speckle 50% of the surface using Taupe. Allow to dry completely before proceeding.
4. Spray 50% of the surface using Black Webbing Spray diagonally. Allow to dry completely before proceeding
5. Spray 40% of the surface using White Webbing Spray diagonally.
6. Allow surface to completely dry and then apply Granicrete Crystal Top Epoxy per product instructions.

Professional Tip: Constantly shake up FX colors while being used in a spray bottle. The powder within each FX color is what makes them unique. If the color rest in the spray bottle the powder will settle to the bottom.

Cherry Web Notes: