

# OBSIDIAN

EASYDIY COLOR	MIXING	SPRAY BOTTLE SETTING	APPROXIMATE SURFACE COVERAGE	BEFORE NEXT STEP	TIME TO DO
GROUTLINE GREY	3 CAPS to 24 oz. water	Mist	100%	With blotting towel rub color into the surface.	15 min.
CHARCOAL ACRYLIC CONCRETE STAIN	4 oz. to 4 oz. water	Mist	100%	<ol style="list-style-type: none"><li>1. Lightly blot surface.</li><li>2. Leave surface still wet.</li><li>3. Then allow to dry completely before next step.</li></ol>	15 min.
CHARCOAL ACRYLIC CONCRETE STAIN	20 oz. straight	Mist	100%	Allow to dry as is. No need to blot. Wait one day before next step.	5 min.

**With surface dry, rinse with water by wiping it with a damp-wet blotting towel.  
Then wait another full day before sealing.**

